




Fig.11 Transfer Case For Front Drive

FIG NO.	SER NO.	FIG/SER. NO.	PART NO.	PART NAME	QTY.
11				TRANSFER CASE FOR FRONT DRIVE	254
11	1	F11S1	GB/T879-8×35	PIN 8×35	1
11	2	F11S2	184.42.109	COUPLING (II)	1
11	3	F11S3	GB/T308-8	STEEL BALL 8	12
11	4	F11S4	184.42.117	WASHER	2
11	5	F11S5	GB/T894.1-24	CIRCLIPER 24	2
11	6	F11S6	184.42.113	DUST CAP	2
11	7	F11S7	254.42.110	SHAFT	1
11	8	F11S8	GB/T879-4×35	PIN 4×35	1
11	9	F11S9	GB3452.1-54.5×3.55	O-RING 54.5×3.55	1
11	10	F11S10	184.42.127-1	FRONT FIXED SEAT	1
11	11	F11S11	GB/T93-8	WASHER 8	20
11	12	F11S12	GB/T5783-M8×20	BOLT M8×20	18
11	13	F11S13	254.42.013	INNER PIPE WELDMENT	1
11	14	F11S14	184.42.111	RUBBER PIPE	1
11	15	F11S15		CLAMP 55-65	2
11	16	F11S16	254I.42.012	OUTER PIPE WELDMENT	1
11	17	F11S17	12.37.148	DUST CAP	1
11	18	F11S18	184.42.107	SPRING	1
11	19	F11S19	184.42.112	COUPLING (I)	1
11	20	F11S20	GB3452.1-58×3.55	O-RING 58×3.55	1
11	21	F11S21	254I.42.114	OIL SEAT	1
11	22	F11S22	GB/T9877.1-25×47×7	OIL SEALING FB25×47×7	2
11	23	F11S23	GB/T276-305	ROLLING BEARING 305	1
11	24	F11S24	254I.42.106	SHAFT	1

11	25	F11S25	GB3452.1-15×2.65	O-RING 15×2.65	1
11	26	F11S26	184.42.103	MIDDLE SHAFT	1
11	27	F1S27	GB/T5783-M6×12	BOLT M6×12	1
11	28	F11S28	GB/T93-6	WASHER 6	1
11	29	F11S29	184.42.115	CHECK LEAF	1
11	30	F11S30	254I.42.102-1	CASE	1
11	31	F11S31	GB/T1152-M10×1	GREASE M10×1	2
11	32	F11S32	12.37.146	WASHER	1
11	33	F11S33	GB/T5786-M16×1.5×1.8	BOLT M16×1.5×1.8	1
11	34	F11S34	160.21.118	BUSH	2
11	35	F11S35	184.42.105	GASKET	2
11	36	F11S36	184.42.104	REAR COVER	1
11	37	F11S37	GB/T5783-M8×35	BOLT M8×35	2
11	38	F11S38	GB/T120-B8×20	PIN B8×20	2
11	39	F11S39	254I.42.102	GASKET	1
11	40	F11S40	GB/T276-204	ROLLING BEARING 204	2
11	41	F11S41	GB/T893.1-47	CIRCLIP 47	1