




Fig. 18 Fuel Tank

NO.	SER NO.	FIG/SER. NO.	PART NO.	PART NAME	QTY.
18				FUEL TANK II	254
18	1	F18S1	250.50.012	STEEL BAND	1
18	2	F18S2	184.50.101	RUBBER CUSHION	2
18	3	F18S3	160.50.014	FUEL TANK CAP	1
18	4	F18S4	160.50.015	SCREEN	1
18	5	F18S5	250.50.011-3	FUEL TANK	1
18	6	F18S6	250.50.103	FRONT SUPPORT	1
18	7	F18S7	160.50.107	DRAIN PLUG	1
18	8	F18S8	GB308	FUEL FLOAT ASSY	1

18	9	F18S9	180.50.021	SEDIMENT CUP ASSY	1
18	10	F18S10	GB/T848-10	WASHER 10	2
18	11	F18S11	180.50.015-2	OUT-LET	1
18	12	F18S12	GB/T93-8	WASHER 8	3
18	13	F18S13	GB/T5783-M8×20	BOLT M8×20	3
18	14	F18S14	184.50.105	FRONT RUBBER CUSHION	1
18	15	F18S15	184.50.102-1	REAR RUBBER CUSHION	1
18	16	F18S16	GB/T5783-M10×20	BOLT M10×20	8
18	17	F18S17	250.50.013-1	SUPPORT PLATE	1
18	18	F18S18	GB/T93-10	WASHER 10	10
18	19	F18S19	GB/T6170-M10	NUT M10	2
18	20*	F18S20	180YZ.50.104-3	REAR SUPPORT FOR HYDRAULIC	1
18	20	F18S20	250.50.112-1	REAR SUPPORT	1
18	21	F18S21	184.50.501	RUBBER RING	1